


e-SIM Activation Steps

F509

5G NR AX900


Wi-Fi 6 Mobile Hotspot

1 / Power on the device.



2 / Connect the PC to the device using the USB cable or WiFi, then log in to the web interface using the information on the label.


https://192.168.125.1
Device Password: XXXXXXXXXX




2.4GHz Wi-Fi Name: F509-XXXX
5GHz Wi-Fi Name: F509-XXXX-5G
Wi-Fi Password: XXXXXXXXXX



3 / <Network>→<eSIM Configuration>→1.WiFi Settings: Enable WiFi and search for networks.




4 / Enter the SSID and Wi-Fi password to connect to a Wi-Fi network with internet access.







- 5 / <Network>→<eSIM Configuration>→2.eSIM Configuration: (1) Enter the LPA activation code, or drag a QR code image(or click to upload), (2) Some carriers require an SM-DP+ or ePIN, enter it here, then click <OK>.




Example : To configure an eSIM profile, you need to scan a QR code and enter an ePIN.



- 6 / The eSIM profile is downloading, and it will be installed successfully after a few moments, then click <Reboot>.



- 7 / Wait for the F509 to reboot, then click <Enable> to activate the eSIM.



- 8 / The F509 uses eSIM to connect to 5G NR or LTE networks.

